

# DFS 910 Bus Machine Fittings

## Top Drawer

### Left Side



--	--

**Part # 7112**

Maxforce 716, Maxforce 7V8



--	--

**Part # DFS 910-2**

Maxforce 10, Cummings ISB 6.7



--	--

**Part # DFS 910-20**

MB-Sprinter



--	--

**Part # DFS 910-6**

Dumax 6.6

### Right Side



**Part # DFS 910-3**

S-Hook Sprayer



**Part # DFS 910-5**

INT VT 365



**Part # LOOP**

Maxforce 7V8, Int VT 365, CAT C-7



**Part# DFS 910-5A**

Diverter Valve with Quick Connects

**Next Page**

## Top Drawer - Left Side



**Part # DFS 910-9**  
Cummins EGR Opener



**Part # DFS 910-33**

## Drawer #2 Left Pocket



**Qty 2. Part # 060-0450**  
Clamps - different sizes



**Qty 2. Part # 7109**  
Maxforce 7V8, Int VT 365



**Qty 2. Part # 7108**  
Maxforce 7V8, Int VT 365



**Part # UCF516**

## Middle Pocket



**Qty 2. Part # 7114**    
Maxforce 716, INT DT 466



**Qty 2. Part # 7115**    
International Fuel Fitting



**Qty 2. Part # UMQD38**    
MB-SPRINTER, DURAMAX 6.6



**Qty 2. Part # UFQD38**    
MB-SPRINTER, DURAMAX 6.6

**Drawer #2**  
**Left Pocket**



Part # UC516



Part # UCF38



Part # UC38

**Middle Pocket**



Qty 2. Part # UMQD516



Qty 2. Part # UFQD516



Part # UMQD12    
DURAMAX 6.6



Part # UFQD12    
DURAMAX 6.6



Part # GMFQD38



Part # GMFQD516

**Drawer #2**  
**Right Pocket**



**Part # HMP14**



**Part # HFP14**



**Part # UM38**



**Part # UF38**



**Part # UM516**



**Part # UF516**

**Drawer #3**  
**Left Pocket**



--	--

Part # M45-4



--	--

Part # F45-4



--	--

Part # M45-5



--	--

Part # F45-5



--	--

Part # M45-6



--	--

Part # F45-6

**2nd Pocket**



Part # M45-8

--	--



Part # F45-8

--	--

**3rd Pocket**



Part # M45-10

--	--



Part # F45-10

--	--

**4th Pocket**



Part # 7070

--	--

INT DT 444, CAT C-7



Part# 7071

--	--

CAT C-7

### 4th Drawer



--	--

Part# DFS 910-1

Manual and Serial # Envelope  
Bus Fitting List

--	--